

Care and Maintenance of Stainless Steel

For the preservation of stainless steel Metaltech uk strongly recommends regular maintenance. The following provides a guide to preserving stainless.

Exterior

Like all surfaces, stainless steel requires cleaning to remove dirt and grime to keep it in pristine condition. The level of cleaning and maintenance required depends primarily on the environment. In some exterior instances normal rain washing is sufficient, but in more polluted or corrosive environments, e.g. coastal situations, the surfaces require regular washing to retain their good looks.



The type of finish will also influence the cleaning required, and it is recommended that the rougher the surface the more regularly cleaning is required. For example, Stainless Steel Wire has a rough surface with crevices that harbour corrosive agents which cause discolouration relatively quickly. Regular cleaning is required to remove this.

Coastal Situations

Discolouration or tea staining most commonly occurs within 5 kilometres of the coast and becomes progressively worse closer to the water. Note that in situations right on the seafront, it is recommended that cleaning is performed once a month.

Interior

Dirt and grease accumulate from many sources. They can usually be removed by routine cleaning using soap, ammonia or detergent and fresh warm water. It should be noted that nearly all abrasive cleaners will scratch bright polished stainless steel surfaces. On other finishes the cleaners should only be used in the direction of the polish.

A clean, dust and grit free cloth should be used to avoid scratching. In all cases the mildest cleaning procedure that will do the job efficiently should be used, e.g. wash down with warm fresh water and washing up liquid followed by a wash of clean warm water only followed by wiping dry with a clean absorbent cloth.

For textured and rigidized finishes a nylon bristled brush will remove any dirt and grime which may accumulate in the valleys of the textured finish.

Swimming Pools

Working environments can also provide aggressive conditions such as heat and humidity in swimming pool buildings. These conditions can result in surface discolouration of stainless steels and so maintenance on a more frequent basis may be required.

Cleaning Methods for Stainless Steel

Stainless steel is easy to clean. Washing with soap or mild detergent and warm water followed by a clear water rinse is usually quite adequate for domestic and architectural equipment. Where stainless steel has become extremely dirty with signs of surface discolouration (perhaps following periods of neglect, or misuse) alternative methods of cleaning can be used, as outlined below.

Requirement	Suggested Method ^{1,2}	Comments
Routine cleaning of light soiling	Soap, detergent or dilute (1%) ammonia solution in warm clean water. Apply with a clean sponge, soft cloth or soft-fibre brush then rinse in clean water and dry ⁶	Satisfactory on most surfaces
Fingerprints	Detergent and warm water, alternatively, hydrocarbon solvent	Proprietary spray-applied polishes available to clean and minimise remarking
Oil and grease marks	Hydrocarbon solvents (methylated spirit, isopropyl alcohol or acetone) ²	Alkaline formulations are also available with surfactant additions e.g. 'D7' Polish ¹
Stubborn spots, stains and light discolouration. Water marking. Light rust staining	Mild, non-scratching creams and polishes. Apply with soft cloth or soft sponge and rinse off residues with clean water and dry ^{6,7} .	Avoid cleaning pastes with abrasive additions ³ . Suitable cream cleansers are available with soft calcium carbonate additions, e.g. 'Jif', or with the addition of citric acid, e.g. Shiny Sinks ¹ . Do not use chloride solutions ^{8,9} .
Localised rust stains caused by carbon steel contamination	Proprietary gels, or 10% phosphoric acid solution (followed by ammonia and water rinses), or oxalic acid solution (followed by water rinse). ⁶	Small areas may be treated with a rubbing block comprising fine abrasive in a hard rubber or plastic filler. Carbon steel wool should not be used, nor should pads that have previously been used on carbon steel. A test should be carried out to ensure that the original surface finish is not damaged.
Burnt on food or carbon deposits	Pre-soak in hot water with detergent or ammonia solution. Remove deposits with nylon brush and fine scouring powder if necessary. Repeat if necessary and finish with 'routine cleaning'.	Abrasive scouring powder can leave scratch marks on polished surfaces.
Tannin (tea) stains and oily deposits in coffee urns	Tannin stains - soak in a hot solution of washing soda i.e. sodium carbonate. Coffee deposits - soak in a hot solution of baking soda (sodium bicarbonate).	These solutions can also be applied with a soft cloth or sponge. Rinse with clean water. Satisfactory on most surfaces.
Adherent hard water scales and mortar/cement splashes	10-15 volume % solution of phosphoric acid. Use warm, neutralise with dilute ammonia solution, rinse with clean water and dry ⁶ . Alternatively soak in a 25% vinegar solution and use a nylon brush to remove deposits.	Proprietary formulations available with surfactant additions. Take special care when using hydrochloric acid based mortar removers ^{8,9} .

Requirement	Suggested Method ^{1,2}	Comments
Heating or heavy discolouration	a) Non-scratching cream or polish e.g. Solvol Auto Chrome Metal Polish ^{1,9} b) Nylon-type pad, e.g. 'Scotchbrite' ^{3,4,5}	a) Creams are suitable for most finishes, but only use 'Solvol' on bright polished surfaces. Some slight scratching can be left. b) Use on brushed and polished finishes along the grain.
Badly neglected surfaces with accumulated grime deposits	A fine, abrasive paste as used for car body refinishing, e.g. 'T-cut' rinsed clean to remove all paste material and dried ¹ .	May brighten dull finishes. To avoid a patchy appearance, the whole surface may need to be treated.
Paint, graffiti	Proprietary alkaline or solvent paint strippers, depending upon paint type. Use soft nylon or bristle brush on patterned surfaces.	Apply as directed by manufacturer.

Notes

- The products referenced in this information sheet are understood to be suitable for stainless steels. However, no endorsement of the products or their manufacturers is implied and it is acknowledged that other manufacturing companies may provide products of equal or better quality. The following companies manufacture proprietary names mentioned: - 'Jif' - Lever Brothers Ltd, 'Shiny Sinks' - Home Products Ltd, 'Ajax' - Colgate Palmolive Ltd, 'D7 Stainless Steel Polish' - Diversey Ltd, 'T-Cut' - Automotive Chemicals Ltd and 'Solvol Auto Chrome Metal Polish' - Hammerite Products Ltd.*
- Cleaning agents should be approved for use under the relevant national environmental regulations and, in addition, prepared and used in accordance with the manufacturers or suppliers' health & safety instructions. Solvents should not be used in enclosed areas.*
- Nylon abrasive pads should be adequate for dealing with most deposits. If a more severe treatment is needed to mask coarse scratches or physical damage on a surface, use the finest abrasive medium consistent with covering the damage marks. With directional brushed and polished finishes, align and blend the new "scratch pattern" with the original finish, checking that the resulting finish is aesthetically acceptable. Silicon carbide media may be used, especially for the final stages of finishing. Avoid using hard objects such as knife blades and certain abrasive/souring agents as it is possible to introduce surface scuffs and scratches. Scratching is particularly noticeable on sink drainer areas. These are usually superficial and can be removed with proprietary stainless steel cleaners or, alternatively, with a car paint restorer, such as 'T-cut'.*
- If wire brushes are used, these should be made of a similar or better grade of stainless steel. Ensure that all abrasive media used are free from sources of contamination, especially iron and chlorides.*
- When cleaning a surface with any chemical preparation or abrasive medium, a trial should be done on a small, unobtrusive hidden or non-critical area of the surface, to check that the resulting finish matches with the original.*
- To avoid water marks, use clean rinsing water, such as reasonable quality potable (tap) water. Drying marks may be avoided using an air blower or wiping with clean disposable wipes.*
- Rust marks or staining on stainless steels is unlikely to be the result of corrosion to the stainless steel itself (similar marks may also be found on porcelain and plastic sinks). These marks are likely to result from small particles of carbon steel from wire wool.*

Information courtesy of British Stainless Steel Association.



Unit 2, Fowler Road, West Pitkerro Industrial Estate, Dundee, DD5 3RU

t: +44 (0) 1382 773910 e: info@mt-uk.com www.mt-uk.com

VAT registration no: 925 0831 35 Metaltech uk Limited, Registered in Scotland No. SC334096

